

New

Medium-Pressure Link Clamp



Model TQA

Hydraulic Link Clamp

Operating Pressure : 2~21MPa

Medium-Pressure Link Clamp

Hydraulic Double Action

Model TQA



Compact Medium-Pressure Clamp

Lightweight and space-saving fixture design. Unclamp Confirmation Option Selectable.


Compact Medium-Pressure Clamp

Body Size : ϕ 20mm

Operating Pressure : 2 ~ 21MPa

※In case of Standard Model

Clamping Force Max. 1.5 kN




● Features

● Thin Fixture Plate

The dimension below flange is short to enable thinner and lighter fixtures.


The flange is also compact, allowing for installation in limited spaces.



● Protective Wall Prevents Damage to Dust Seal


The protective wall prevents damage to the internal dust seal and maintains high sealing over an extended period.

The dust seal also has high durability against chlorine-based coolant by using a sealing material with excellent chemical resistance.




● Unclamp Confirmation

An air sensor enables unclamp confirmation.



● Easy Machining of Cartridge Cavity

Cartridge cavity does not require any special tooling for recess machining. The maximum corresponding port hole diameter is large, allowing for easy machining.




● Action Description

Standard Model (No Action Confirmation)


In case of **3** Action Confirmation Symbol : Blank

※ Refer to the 'model no. indication' on P.7 for the action confirmation symbol.



■ Clamping Action

The piston rod ascends and clamps the workpiece.



■ Unclamping Action


The piston rod descends.

Unclamp Confirmation Model

Unclamp operation can be confirmed using an air sensor.

In case of **3** Action Confirmation Symbol : **Unclamp Confirmation**



※ Refer to the 'model no. indication' on P.7 for the action confirmation symbol.



■ Clamping Action

The piston rod ascends and clamps the workpiece. The spool is pushed upward by the built-in spring and the unclamp confirmation valve is opened.


Hydraulic Pressure		Air Sensor
Clamp Side	Unclamp Side	Unclamp Check Output
ON	OFF	OFF



■ Unclamping Action

The piston rod descends. The spool is pushed downward compressing the built-in spring and the unclamp confirmation valve is closed.

Hydraulic Pressure		Air Sensor
Clamp Side	Unclamp Side	Unclamp Check Output
OFF	ON	ON



● Action Description (Action Confirmation and Air Sensing Chart)

Action confirmation can be conducted by detecting differential pressure with an air sensor.

Applicable Model

TQA 016 0 - J - Blank A

3 Action Confirmation Symbol
J : Unclamp Confirmation

Air Sensor

- Air catch sensor is required in order to conduct the action confirmation.


Sensing can be done by the air catch sensor with small air flow (recommended models are in the chart below).

Recommended Operating Air Pressure : 0.1~0.2MPa

Recommended Air Sensor



Manufacturer	SMC	CKD
Name	Air Catch Sensor	Gap Switch
Model No.	ISA3-G	GPS3-E

- Please refer to manufacturer's catalog or other documents for the details about the air catch sensor.
- The air pressure to the air catch sensor should be 0.1~0.2MPa.
- Please keep supplying air pressure when in use.
- Refer to the drawing below for the air circuit structure.



Notes for Design • Installation • Use

- Please keep clear condition at the air vent port / vent hole, and prevent coolant and chips from entering the port / hole. The air sensor can malfunction if the air vent port is blocked.
- Prevention of Contaminants to the Air Vent Port / Vent Hole
Coolant and chips can be prevented by setting a check valve. (Recommended check valve: SMC-made series AKH, cracking pressure: 0.005MPa)





- Keep clear condition at the air vent port / hole. ✕ Coolant and chips enter from the air vent hole.

- Keep supplying air pressure to the air port when in use.

Air Sensing Chart

When Connected to 1 Clamp, Supply 0.2MPa Air Pressure



※ This drawing shows the clamped state.

Notes :

1. The sensing chart shows the relationship between the stroke and detection circuit air pressure
2. The specifications may vary depending on the air circuit. The length of hose should be as short as possible. (Suggest shorter than 5m)

※1. The location of ON signal from air sensor output varies depending on the sensor setting.

※2. The sensor pressure for opening the valve depends on the sensor.

With air sensor with large air flow, the sensor pressure for opening the valve is higher and the differential pressure for detection is lower.

Model No. Indication


TQA 016 0 - J - A

1 2 3 4

1 Body Size (Clamping Force)

016 : $\phi D=20\text{mm}$

※ Outer diameter (ϕD) of the cylinder.



2 Design No.

0 : Revision Number

3 Action Confirmation Symbol


Blank : Standard (no action confirmation)

J : Unclamp Confirmation

4 Lever Option

Blank : Lever not included

A : Standard Lever included



Specifications

Model No.		TQA0160 TQA0160-A	TQA0160-J TQA0160-J-A
Cylinder Area for Clamping	cm ²	0.950	
Cylinder Inner Diameter ※1	mm	11	
Rod Diameter ※1	mm	8	
Clamping Force ※2 (Calculation Formula)	kN	$F = \frac{0.90 \times P}{L - 10.5}$	
Full Stroke	mm	13.0	
Clamp Stroke	mm	11.5	
Extra Stroke	mm	1.5	
Cylinder Capacity	Clamp	cm ³	1.2
	Unclamp	cm ³	0.6
Hydraulic Pressure	Max. Operating Pressure	MPa	21.0
	Min. Operating Pressure ※3	MPa	2.0
	Withstanding Pressure	MPa	31.5
Recommended Operating Air Pressure		MPa	0.1 ~ 0.2
Recommended Air Sensor			ISA3-G : SMC-made / GPS3-E:CKD-made
Operating Temperature		°C	0 ~ 70
Usable Fluid		General Hydraulic Oil Equivalent to ISO-VG-32	
Weight	4 Lever Option Blank	kg	0.11
	4 Lever Option A	kg	0.13


Notes : ※1. Clamping force cannot be calculated from the cylinder inner diameter and rod diameter.

Please refer to the clamping force calculation formula and the clamping force curve.


※2. F : Clamping Force (kN), P : Supply Hydraulic Pressure (MPa),

L : Distance between the piston center and the clamping point (mm).

※3. Minimum pressure to operate the clamp without load.




Clamping Force Curve



(How to Read the Clamping Force Curve)

When supply hydraulic pressure P is 21MPa and lever length L is 23mm, clamping force becomes about 1.51kN.

TQA0160		Clamping Force Calculation Formula ※5 (kN)					$F = \frac{0.90 \times P}{L - 10.5}$			
Hydraulic Pressure (MPa)	Cylinder Force (kN)	Clamping Force (kN)								Min. Lever Length (L) (mm)
		Lever Length L (mm)								
		15	17	19.5	23 Std. Lever	26	30	35	40	
21	2.00				1.51	1.22	0.97	0.77	0.64	23
18	1.71			1.80	1.30	1.05	0.83	0.66	0.55	19.5
15	1.43		2.08	1.50	1.08	0.87	0.69	0.55	0.46	17
14	1.33		1.94	1.40	1.01	0.81	0.65	0.51	0.43	16.5
12	1.14		1.66	1.20	0.86	0.70	0.55	0.44	0.37	15.5
10	0.95	2.00	1.38	1.00	0.72	0.58	0.46	0.37	0.31	15
9	0.86	1.80	1.25	0.90	0.65	0.52	0.42	0.33	0.27	15
7	0.67	1.40	0.97	0.70	0.50	0.41	0.32	0.26	0.21	15
6	0.57	1.20	0.83	0.60	0.43	0.35	0.28	0.22	0.18	15
5	0.48	1.00	0.69	0.50	0.36	0.29	0.23	0.18	0.15	15
2	0.19	0.40	0.28	0.20	0.14	0.12	0.09	0.07	0.06	15
Max. Operating Pressure (MPa)		11.9	15	18	21	21	21	21	21	



Notes :

※5. F : Clamping Force (kN), P : Supply Hydraulic Pressure (MPa), L : Lever Length (mm)


Cylinder output (when L=0) cannot be calculated from the calculation formula of clamping force.

1. The table and the graph show the relationship between the clamping force (kN) and supply hydraulic pressure (MPa).
2. Values in the chart indicate clamping force when the lever locks a workpiece in horizontal position.
3. The clamping force varies depending on the lever length. Set the suitable supply hydraulic pressure based on the lever length.


External Dimensions

TQA0160-☐ : Standard (No Action Confirmation)


※ The drawing shows the clamped state of **TQA0160-A**.




4 Lever Option: A




4 Lever Option: **Blank** ※1




● Machining Dimensions of Mounting Area



For Blind Hole



For Through Hole



Note :

※3. Tapping depth of the mounting bolt should be decided according to the length of the bolt.

Notes :

※1. Please refer to **4** Lever Option : **A** for unlisted dimensions.


※2. Mounting bolts are not included. Please prepare them by customer.

1. Please use the provided pin (equivalent to $\phi 4f6$, HRC60) as the lever mounting pin.


External Dimensions

TQA0160-J-□ : Unclamp Confirmation


※ The drawing shows the clamped state of TQA0160-J-A.



4 Lever Option : A




4 Lever Option : Blank ※4




Notes :

- ※4. Please refer to 4 Lever Option : A for unlisted dimensions.
- ※5. Mounting bolts are not included. Please prepare them by customer.
- ※6. Please keep clear condition at the air vent hole, and prevent coolant and chips from entering the hole.
- 1. Please use the provided pin (equivalent to φ4f6, HRC60) as the lever mounting pin.


Machining Dimensions of Mounting Area



For Blind Hole



For Through Hole




Note :

- ※7. Tapping depth of the mounting bolt should be decided according to the length of the bolt.
- ※8. Prepare the vent hole on the side or the bottom.
When preparing on the side, it should be within the ◆ area.
When preparing on the bottom, it should be within φ18.

Link Lever Design Dimensions

※ Reference for designing link lever for TQA0160.



Notes :

1. Please design the link lever length according to the performance curve.
2. If the link lever is not in accordance with the dimensions shown above, performance may be degraded and damage can occur.
3. Use the attached pin (equivalent to φ 4f6, HRC60) as the lever mounting pin.

● Cautions

● Notes for Design

1) Check Specifications


- Please use each product according to the specifications.

2) Notes for Circuit Design


- Please read "Notes on Hydraulic Cylinder Speed Control Unit" for proper hydraulic circuit design. Improper circuit design may lead to malfunctions and damages.
- Ensure there is no possibility of supplying hydraulic pressure to the clamp port and the unclamp port simultaneously.

3) Notes for Link Lever Design

- Make sure no force is applied to the piston rod except from the axial direction. The usage like the one shown in the drawing below will apply a large bending stress to the piston rod and must be avoided.



- Offset lever cannot be used. Offset load may damage the product.




4) Protect the exposed area of the piston rod when using on a welding fixture.

- If spatter attaches to the sliding surface it could lead to malfunction and fluid leakage.

5) When clamping on a sloped surface of the workpiece

- Make sure the clamping surface and the mounting surface of the clamp are parallel.



6) When using TQA-J-□

- Make sure to check the notes for design, installation and use on P.5 in case of air sensing with an air sensor.

7) When using in a dry environment.

- The link pin can be dried out. Please grease it periodically.

8) The cartridge cavity of the clamp should be machined as shown in the external dimensions.

The external o-ring may be damaged when it passes through the port on the inner wall of the hole.



● Notes on Hydraulic Cylinder Speed Control Unit

Please pay attention to the cautions below.




Design the hydraulic circuit for controlling the action speed of hydraulic cylinder. Improper circuit design may lead to malfunctions and damages.

Please review the circuit design in advance.

● Flow Control Circuit for Double Acting Cylinder

In the case of controlling the speed of TQA, both clamp side and unclamp side should be meter-in circuit. If meter-out circuit is used, abnormal high pressure is created, which causes oil leakage and damage.

【Meter-in Circuit】



Cautions

Installation Notes

1) Check the Usable Fluid

- Please use the appropriate fluid by referring to the Hydraulic Fluid List.

2) Procedure before Piping

- The pipeline, piping connector and fixture circuits should be cleaned by thorough flushing.
- The dust and cutting chips in the circuit may lead to fluid leakage and malfunction.
- There is no filter provided with Kosmek's product except for a part of valves which prevent contamination in the circuit.

3) Applying Sealing Tape

- Wrap with tape 1 to 2 times following the screw direction.
- Pieces of the sealing tape can lead to oil leakage and malfunction.
- Please implement piping construction in a clear environment to prevent anything getting in products.

4) Be careful not to damage the O-ring.

- If installed in a dry state, the external o-ring may be damaged. Apply an appropriate amount of grease to the cartridge cavity to prevent the external O-ring from being caught. Stable detection may not be possible if the grease remains inside the clamp.


5) Installation / Removal of the Product

- For installation, use four hexagonal socket bolts (with tensile strength of 12.9) and tighten them with the torque shown in the table below. Tightening with greater torque than recommended can dent the seating surface or break the bolt.

Model No.	Mounting Bolt Size	Tightening Torque (N·m)
TQA0160	M4×0.7	3.2

- For removal, use a jacking bolt (mounting bolt hole) shown in the table below to avoid damaging the fixing threads. The following image shows a case where a parallel pin (set screw) is inserted in the screw hole to prevent damage to the fixing thread.

Model No.	Jacking Bolt Size
TQA0160	M5×0.8



6) Trial Operation Method

- There is a lot of air in the circuit just after installation. If high pressure with large flow rate is supplied under such condition, action time will be extremely fast leading to severe damage on a clamp. Make sure to perform running-in operation with low pressure with small flow rate and bleed the air in the circuit.


7) Speed Adjustment

- Adjust the speed so that the total operating time for both clamp and unclamp is 0.5 seconds or more. If the clamp operates too fast, the parts will be worn out, leading to premature damage and ultimately complete equipment failure.
- Please make sure to release air from the circuit before adjusting speed. It will be difficult to adjust the speed accurately with air mixed in the circuit.
- Turn the speed control valve gradually from the low-speed side (small flow) to the high-speed side (large flow) to adjust the speed.


8) Air Bleeding of the Hydraulic Circuit

- If the hydraulic circuit has excessive air, the action time may become very long. If air enters the circuit after connecting the hydraulic port or under the condition of no air in the oil tank, please perform the following steps.

- Reduce hydraulic pressure to less than 2MPa.
- Loosen the cap nut of pipe fitting closest to the clamp, cylinder, work support, etc. by one full turn.
- Shake the pipeline to loosen the outlet of pipe fitting. Hydraulic fluid mixed with air comes out.



- Tighten the cap nut after air bleeding.
- It is more effective to release air at the highest point inside the circuit or at the end of the circuit. (For the gasket option, set an air bleeding valve at the highest point inside the circuit.)




9) Checking Looseness and Retightening

- At the beginning of the product installation, the bolt and nut may be tightened lightly. Check the looseness and re-tighten as required.

10) Installation / Removal of the Link Lever

- When inserting the link pin, do not hit the pin directly with a hammer. When using a hammer to insert the pin, always use a cover plate with a smaller diameter than the spring ring groove on the pin.



Hydraulic Fluid List

Manufacturer	ISO Viscosity Grade ISO-VG-32	
	Anti-Wear Hydraulic Oil	Multi-Purpose Hydraulic Oil
Showa Shell Sekiyu	Tellus S2 M 32	Morlina S2 B 32
Idemitsu Kosan	Daphne Hydraulic Fluid 32	Daphne Super Multi Oil 32
JX Nippon Oil & Energy	Super Hyrando 32	Super Mulpus DX 32
Cosmo Oil	Cosmo Hydro AW32	Cosmo New Mighty Super 32
ExxonMobil	Mobil DTE 24	Mobil DTE 24 Light
Matsumura Oil	Hydol AW-32	
Castrol	Hyspin AWS 32	

Note : Please contact manufacturers when customers require products in the list above.

● Notes on Handling

- 1) It should be operated by qualified personnel.
 - The hydraulic machine and air compressor should be operated and maintained by qualified personnel.
- 2) Do not operate or remove the product unless the safety protocols are ensured.
 - ① The machine and equipment can only be inspected or prepared when it is confirmed that the safety devices are in place.
 - ② Before the product is removed, make sure that the above-mentioned safety devices are in place. Shut off the pressure and power source, and make sure no pressure exists in the hydraulic and air circuits.
 - ③ After stopping the product, do not remove until the temperature drops.
 - ④ Make sure there is no abnormality in the bolts and respective parts before restarting the machine or equipment.
- 3) Do not touch the clamp while it is working.
Otherwise, your hands may be injured due to clinching.



- 4) Do not disassemble or modify.
 - If the equipment is taken apart or modified, the warranty will be voided even within the warranty period.
- 5) Do not use deformed snap rings.
 - When installing or replacing a lever, do not use open-mouthed or deformed snap rings for link pin. Snap rings may not be attached properly.


● Warranty

- 1) Warranty Period
 - The product warranty period is 18 months from shipment from our factory or 12 months from initial use, whichever is earlier.
- 2) Warranty Scope
 - If the product is damaged or malfunctions during the warranty period due to faulty design, materials or workmanship, we will replace or repair the defective part at our expense.
Defects or failures caused by the following are not covered.
 - ① If the stipulated maintenance and inspection are not carried out.
 - ② If the product is used while it is not suitable for use based on the operator's judgment, resulting in defect.
 - ③ If it is used or operated in an inappropriate way by the operator. (Including damage caused by the misconduct of the third party.)
 - ④ If the defect is caused by reasons other than our responsibility.
 - ⑤ If repair or modifications are carried out by anyone other than Kosmek, or without our approval and confirmation, it will void warranty.
 - ⑥ Others caused by natural disasters or calamities not attributable to our company.
 - ⑦ Parts or replacement expenses due to parts consumption and deterioration. (Such as rubber, plastic, seal material and some electric components.)

Damages excluding from direct result of a product defect shall be excluded from the warranty.

● Maintenance and Inspection

- 1) Removal of the Product and Shut-off of Pressure Source
 - Before the product is removed, make sure that safety devices and preventive devices are in place. Shut off the pressure and power source, and make sure no pressure exists in the hydraulic and air circuits.
 - Make sure there is no abnormality in the bolts and respective parts before restarting.
- 2) Regularly clean the area around the piston rod and the link.
 - If it is used when the surface is contaminated with dirt, it may lead to packing seal damage, malfunctioning and fluid leakage.



- 3) If disconnecting by couplers, air bleeding should be carried out on a regular basis to avoid air mixed in the circuit.
- 4) Regularly check the condition of the air sensor settings.
Due to wear of internal components, the condition may change from the initial setting. Regularly check and adjust as necessary.
- 5) Regularly tighten pipes and mounting bolts to ensure proper use.
- 6) Make sure the hydraulic fluid has not deteriorated.
- 7) Make sure there is a smooth action without an irregular noise.
 - Especially when it is restarted after left unused for a long period, make sure it can be operated correctly.
- 8) The products should be stored in the cool and dark place without direct sunshine or moisture.
- 9) Please contact us for overhaul and repair.




KOSMEK LTD.

► <https://www.kosmek.com/>

HEAD OFFICE 1-5, 2-chome, Murotani, Nishi-ku, Kobe-city, Hyogo, Japan 651-2241
TEL.+81-78-991-5162 FAX.+81-78-991-8787

United States of America SUBSIDIARY	KOSMEK (USA) LTD. 650 Springer Drive, Lombard, IL 60148 USA TEL. +1-630-620-7650 FAX. +1-630-620-9015
MEXICO REPRESENTATIVE OFFICE	KOSMEK USA Mexico Office Av. Santa Fe 103, Int. 59, col. Santa Fe Juriquilla, Queretaro, QRO, 76230, Mexico TEL. +52-1-55-3044-9983
EUROPE SUBSIDIARY	KOSMEK EUROPE GmbH Schleppeplatz 2 9020 Klagenfurt am Wörthersee Austria TEL. +43-463-287587 FAX. +43-463-287587-20
CHINA SUBSIDIARY	KOSMEK (CHINA) LTD. Room601, RIVERSIDE PYRAMID No.55, Lane21, Pusan Rd, Pudong Shanghai 200125, China TEL. +86-21-54253000
INDIA BRANCH OFFICE	KOSMEK LTD. - INDIA 4A/Old No:649, Ground Floor, 4th D cross, MM Layout, Kavalbyrasandra, RT Nagar, Bangalore -560032 India TEL.+91-9880561695
THAILAND REPRESENTATIVE OFFICE	KOSMEK Thailand Representation Office 67 Soi 58, RAMA 9 Rd., Phatthanakan, Suanluang, Bangkok 10250, Thailand TEL. +66-2-300-5132 FAX. +66-2-300-5133



- For Further Information on Unlisted Specifications and Sizes, Please call us.
- Specifications in this Leaflet are Subject to Change without Notice.



JQA-QMA10823
KOSMEK HEAD OFFICE